

# SpillEx

**Super-absorbing. Super safe !**



**Dimensions:**

51 x 37 cm

**Colour:**

White

**Packing:**

20pcs per pack

**Stock Code:**

VL146761

**The amount of liquid one SpillEx can absorb depend on the type of liquid. In typical application situation SpillEx is suitable to absorb approx. 500 to 1200ml of liquid.**

**Application area:**

SpillEx is a disposable super absorbing floor cloth designed for fast removal of a wide range of water based spillages from hard floors e.g. blood in operation theatres, urine in elderly homes or to quickly remove soft drink spillages that may cause a slip risk in restaurants or supermarkets. SpillEx ensures fast, safe removal of liquids before actual floor mopping takes place.



**High Absorbency:** SpillEx

contains super absorbing polymers in a high concentration.

**No dripping:** The absorbed water is transformed into gel, the liquid is bonded safe in the cloth, no dripping.

**Hygienic:** Safe handling of liquid contaminations.

**No soiling of cleaning solution:** When working with bucket method use of SpillEx prevents mop contamination, which, which saves time and money.

**How to use:**

1. Put SpillEx onto the spillage with the non-woven, unprinted side down.
2. Wait. The time which is needed to absorb the spillage is depending on the type of liquid (between 30 seconds and 2 minutes). For dried in blood it might be necessary to spray water on the spillage to dilute it. For larger spillages SpillEx can be moved without lifting to cover the remaining spillage area.
3. Remove SpillEx from the floor by grabbing the top side. SpillEx can be disposed with normal residual waste. In case of case of contaminated liquids the internal protocol for infectious waste need to be respected.